



1999-2001 Boxxer Service Guide



1999-2001 Boxxer Service Guide

Removing the Top Caps and Coil Springs	2
Removing the Lower Leg.	3
Removing the Compression and Rebound Assemblies.	4
Servicing the Seals	6
Servicing the Rebound Assembly.	8
Servicing the Compression Assembly	11
Compression and Rebound Assembly Installation	12
Glide Ring Assembly.	12
Installing the Lower Legs	14
Installing the Springs and Oil.	14
International Distributors	16

For exploded diagram and part number information, refer to the 2001 Spare Parts Catalog, P/N 950-005604-00.
Contact your local distributor or visit the RockShox website at www.rockshox.com for ordering information.

Information contained in this publication is subject to change at anytime without prior notice.
For the latest technical information, visit our website at www.rockshox.com.
Names used in this manual may be trademarks or registered trademarks of others.

Tools Needed



- Plastic Faced Mallet
- 3/8 " Ratchet
- Snap Ring Pliers
- Small Flat Blade Screw Driver
- Large Flat Blade Screw Driver
- 4, 6, 22 and 32 mm Socket
- 3 mm Hex Wrench
- Adjustable Wrench
- Dental Pick
- Safety Glasses
- Oil Pan
- Judy Butter
- RockShox 10 and 15 wt. oil
- Boxxer Shaft Installation Tool


REMOVING THE TOP CAPS AND COIL SPRINGS

TIP: RIGHT AND LEFT SIDE IS DETERMINED FROM THE RIDER'S PERSPECTIVE.


1. We recommend removing the fork from both the upper and lower crowns. Loosen the crown bolts with a 4 mm hex wrench.
2. Remove the top caps using a 22 mm socket wrench.
3. Compress the fork and remove the volume spacers.

2

3



4. Remove springs from both sides of the fork.





REMOVING THE LOWER LEG

5. Invert the fork into a large oil pan. Cycle each upper tube until the oil is completely drained from the fork.



6. Using a 6 mm socket wrench, unscrew both shaft bolts three turns. Do not remove shaft bolts completely.





7. With a mallet, tap the shaft bolts to release the internal shafts from the lower legs. Then completely remove the shaft bolts using the 6 mm hex wrench.





8. Remove each upper tube from the lower legs.


REMOVING THE COMPRESSION AND REBOUND ASSEMBLIES



9. With snap ring pliers, remove both snap rings from the upper tubes.



SERVICING THE SEALS

12

12. Use a large flat blade screwdriver to pop the wiper seals out of the lower legs.

13

13. Using snap ring pliers, remove the snap rings on both sides of the lower legs.

14

14. Remove the main seal washer with a dental pick.



15. With a large flat blade screwdriver, remove the main seal from both sides of the lower legs.




16. Lubricate the new main seals inside and out with Judy Butter. Then place a 1-1/4 inch (32 mm) socket on top of the seal. Firmly press on the socket with the palm of your hand to install the seal. Ensure the seal is completely seated in the lower leg.
17. Re-install the main seal washer on both sides (see picture 14).
18. With snap ring pliers, install the snap rings on both sides (see picture 13).



19. Lubricate the inside of the wipers with Judy Butter and press them into the lower legs by hand. Ensure they sit flush on top of the lower legs.

SERVICING THE REBOUND ASSEMBLY

20


- 
20. Remove the end plug on the rebound assembly using an adjustable wrench.

TIP: PLACING THE FLATS ON THE SILVER END OF THE ROD IN A VISE KEEPS IT STATIONARY WHILE REMOVING THE END PLUG.

21

- 
21. Using a dental pick, remove the seal o-ring on the end plug and replace it with a new one.

22

- 
22. Remove the retaining ring from the top of the rebound shaft using the dental pick.

23

23. After removing the retaining ring, remove the wavy washer that sits underneath the retaining ring.

NOTE: KEEP THE SHAFT VERTICAL TO PREVENT THE INTERNALS FROM FALLING OUT.



Steel Pin

24a

24. Install the handle of a flat blade screwdriver in a vice. Then place the rebound assembly on top of the screwdriver and slowly push the internal shaft up until a small steel pin pops up (picture 24a). Once the steel index pin pops up, remove the index plate (picture 24b).

NOTE: BE CAREFUL NOT TO LOSE THE SMALL STEEL BALL THAT SITS UNDER THE INDEX PLATE.




25. Push the internal shaft all the way out. Note the orientation of the internal shaft.

25a




25b





26. Using a dental pic, remove the three o-rings from the internal shaft. All shaft o-rings are identical in specifications. Lubricate the new o-rings and install them onto the shaft.



27. Lubricate the entire internal shaft with a light coat of Judy Butter and slide it into the rebound shaft. Ensure you do not tear the three o-rings you replaced.

The internal shaft had a nub on the end and should face the top end of the rebound shaft. Also notice a hole near the top of the internal shaft. This hole should match with the slit in the outer shaft when the internal shaft is installed all the way.

NOTE: THE INTERNAL SHAFT IS INSTALLED CORRECTLY WHEN YOU CAN SEE THROUGH THE SLIT AND THE END OF THE INTERNAL SHAFT IS FLUSH WITH THE BOTTOM OF THE REBOUND SHAFT.

28. Install the parts from the internal shaft (see picture 25b) in the same orientation they came out in. If they are assembled incorrectly, the rebound adjustment will not function.
29. Lubricate the bottom side of the index plate and place the small steel ball in the round seat on the bottom of the index plate. The grease keeps the small steel ball from falling off the index plate.


30. Place the index plate inside the rebound shaft.

NOTE: THE INDEX PLATE WILL HAVE A HALF CIRCLE ON ONE SIDE. ENSURE THIS HALF CIRCLE MATCHES A HALF CIRCLE ON THE REBOUND SHAFT.

31. Install the pin, wavy washer and retaining ring (see pictures 22 to 24).



32


- 
32. Check the accuracy of the rebuild by inserting a 3 mm hex wrench through the bottom of the rebound shaft assembly. You should be able to make up to a 90-degree adjustment. You should also feel the adjustment clicks when turning the hex wrench.
 33. Using Judy Butter, lubricate the o-ring on the end plug. Then screw the end plug into the rebound shaft. Torque to 30 in-lb.

SERVICING THE COMPRESSION ASSEMBLY

34

- 
34. Remove the end plug from the compression rod assembly using an adjustable wrench.

35a

- 
35. Remove the large o-ring from the end plug and replace it with a new one (picture 35a). Then remove the small o-ring from the top of the end plug and replace it with a new one (picture 35b).

IMPORTANT: DO NOT TAKE THE COMPRESSION VALVE ASSEMBLY APART. THIS ASSEMBLY IS PRESET TO ROCKSHOX SPECIFICATIONS.

- 
36. Lubricate the large o-ring and reinstall the compression end plug using an adjustable wrench.


35b



BOXXER SERVICE GUIDE

GLIDE RING ASSEMBLY

37a



37. If the new steel glide ring energizer is not installed on the new glide ring, install it now.

37b



38



38. Install the new glide ring on the compression shaft and shape it on the shaft with your fingers. Repeat this step on the rebound shaft.

COMPRESSION AND REBOUND ASSEMBLY INSTALLATION

39a



39. Install the negative spring on the rebound shaft. Then slide the rebound shaft assembly through the shaft installation tool. The thin walled side of the tool will face towards the white glide ring. The glide ring will have to be form fitted with your fingers into the tool.

NOTE: THE SHAFT INSTALLATION TOOL CAN BE MADE FROM A ROCKSHOX JUDY SL, XC OR C UPPER TUBE. CUT TWO INCHES FROM THE BOTTOM PORTION OF THE UPPER TUBE. YOU MAY ALSO MAKE THE TOOL USING 28 MM TUBING THAT HAS A 26MM MINIMUM INSIDE DIAMETER.

39b






40. Insert the rebound shaft assembly (with shaft installation tool) into the bottom of the right upper tube until it stops in the upper tube.



41. With the rebound assembly in the upper tube, push the bottom of the shaft up into the upper tube. When the shaft is an inch from the bottom of the upper tube, remove the shaft installation tool. This must be performed to get the glide ring into the upper tube.

42. Repeat steps 39 to 41 to install the compression shaft into the **left upper tube**.



43. Reinstall the rebound and compression base valve assemblies into the bottom of the right and left upper tubes. Refer to picture 11b for the proper orientation of the base valve assembly pieces.
44. Once all the base valve assemblies are installed, proceed to install the snap ring on each upper tube with snap ring pliers.



BOXXER SERVICE GUIDE

INSTALLING THE LOWER LEGS

45. Using Judy Butter, lubricate the inside of the resi-wipers and seals. Then install the lower legs onto the upper tubes making sure not to roll over the resi-wiper lip edge.

NOTE: ADDING A THIN FILM OF OIL ON THE OUTSIDE OF THE UPPER TUBES BEFORE INSTALLATION OF THE LOWER LEGS HELPS THE FORK FEEL SMOOTH IN ITS TRAVEL.

46. Install new crush washers into the crush washer retainers. Slide the crush washer retainer (with crush washer) onto the shaft bolts. Install the shaft bolts into the bottom of the lower legs using a 5 mm hex socket. Torque the shaft bolts to 60 in-lb.

INSTALLING THE SPRINGS AND OIL

IMPORTANT: READ THIS ENTIRE SECTION BEFORE PERFORMING THE FOLLOWING STEPS!

TIP: RIGHT AND LEFT SIDE IS DETERMINED FROM THE RIDER'S PERSPECTIVE.

47. Compress the fork all the way until it bottoms out and ensure there are no springs inside.
48. Install 10 wt. oil into the left upper tube and 15 wt. oil into the right upper tube. There should be 120 mm between the top of the upper tube and where the oil sits.
49. Cycle the upper tubes five or six times. This allows the oil to fill the valve cavities.
50. Compress the upper tubes all the way until they bottom out and measure the oil height again. If the oil has decreased, install the appropriate oil into each upper tube to achieve 120 mm of space between the top of the upper tube and where the oil sits.
51. Install the springs and spring spacers into each upper tube.
52. Using a 22 mm socket, install the top caps and torque to 60 in-lb.
53. Install the upper fork crown and bolts. Torque the fork crown to 65 in-lb.
54. Wipe the fork clean



For further information visit our website at www.rockshox.com or call 1.800.677.7177. If you live outside of the United States, contact the RockShox distributor in your country.



BOXXER SERVICE GUIDE



INTERNATIONAL DISTRIBUTORS

Argentina

Broni S.A.
Phone: 54 11 4292 3000
FAX: 54 11 4292 4453
J.J. PASO 1260, (1832) LOMAS DE ZAMORA,
BUENOS AIRES

Australia

Steve Cramer Products
Phone: 61 3 9587 1466
FAX: 61 3 9587 2018
39 INDUSTRIAL DRIVE BRAESIDE, VICTORIA
3192

Austria

Barisitz-Austria
Phone: 43 512 39 22 87
FAX: 43 512 39 45 19
BERNHARD-HOEFLSTRASSE 14, A-6020,
INNSBRUCK

Belgium

Vertex Cycle Systems BV
Phone: 31 23 57 18184
FAX: 31 23 57 18606
FLEMINGSTRAAT 100A, 2041 VL ZANDVOORT
HOLLAND

Canada

Bell Sports Canada
Phone: 403 273 1427 (Calgary)
FAX: 403 248 1221
BAY 147, 2760 45TH AVE SE
CALGARY, ALBERTA
T2B 3M1

Chile

Bicicletas Belda Limitada
Phone: 56 32 881799
FAX: 56 32 978799
14 NORTE 1001
VINA DEL MAR

Costa Rica

Inversiones Y Sistemes Garvi
Phone: 506 296 3383
FAX: 506 289 7013
P.O. BOX 4805-1000, SAN JOSE

Croatia

Ciklo-Centar
Phone: 385 1 234 22 24
FAX: 385 1 234 34 22
JURJA VES 30A
10000 ZAGREB

Czech Republic

Vanek Praha
Phone: 42 0 312 698 1889
FAX: 42 0 312 698 025
CERRENY UJEZD 185, UNHOST, 27351

Denmark

Duell A/S
Phone: 45 86 36 7800
FAX: 45 86 36 7377
MOLLERUPVEJ 3, TAASTRUP, 8410 RONDE

Ecuador

Bici Sport
Phone 5932 248737
FAX: 5932 253691
AV DE DICIEMBRE 6327, ENTRE LOUVRE Y
TOMAS DE, BERLANGA.LOCAL #3, QUITO

Estonia

Hawaii Express
Phone: 372 6 398 508
FAX: 372 6 398 566
REGATI 1, 5K-102, TALLINN, 11911, Estonia
Or
Estonian Unidream
Phone: 372 636 7470
Fax: 372 636 7470
Paavli 2A, Tallinn
EE0004, Estonia

Finland

Mr. Cool OY
Phone: 358 9 3250817
FAX: 358 9 3250609
LINNAVUORENTIE 28, HELSINKI, 00950

France

Royal Velo France
Phone: 33 325 433 730
Fax: 33 325 43 95 95
4 RUE DES AZALEES, P.A. SUD-CHAMPANGE
ST THIBAULT, 10800

Germany

Sport Import GmbH
Phone: 49 44 05 9280 0
FAX: 49 44 05 9280 49
INDUSTRIESTRASSE 41 B, EDEWECHT, 26188

Greece

Gatsoulis Stefanos Imports
Phone: 30 12512 779
FAX: 30 12533 960
8 THESSALONIKIS STREET, NEW FILADELFIA,
ATHENS, T.T. 14342

Guatemala

BYS Importaciones S.A.
Phone: 502 366 7709
FAX: 502 363 3918
18 CALLE 7-48, ZONA 10, GUATEMALA

Holland

Vertex Cycle Systems BV
Phone: 31 23 57 18184
FAX: 31 23 57 18606
FLEMINGSTRAAT 100A, 2041 VL ZANDVOORT
HOLLAND

Hong Kong

Flying Ball Bicycle Company
Phone: 852 23813661
FAX: 852 23974406
201 TUNG CHOI ST. G/F, MONGKOK KOWLOON

Hungary

Prokero Ltd Co.
Phone 361 331 3184
FAX: 361 331 3184
KALMAN IMRE UTCA 23, BUDAPEST, 1054

Iceland

Orninn Hjol Ltd
Phone: 354 588 9892
FAX: 354 588 9896
SKEIFAN 11, P.O. BOX 8036, REYKJAVIK

Ireland

Madison
Phone: 44 181 385 3385
Fax: 44 208 345 3443
BUCKINGHAM HOUSE EAST, THE BROADWAY
STANMORE, MIDDLESEX HA7 4EA
UNITED KINGDOM

Israel

S.I. Noam
Phone: 972 3659 7928
Fax: 972 3659 7928
4 HA'ATZMAUT AVE,
BAT-YAM, ISRAEL
59441

Italy

Motorquality
Phone: 39 02 24 951 1
FAX: 39 02 24 951 228
20099 SESTO S. GIOVANNI, (MI) I VIA
VENEZIA, (ANG. VIA CARDUCCI), MILANO

Japan

Yoshigai Corporation
Phone: 81 729 88 5461
FAX: 81 729 88 5463
5-19, 1-CHOME, SHIMOROKUMANGI-CHO,
HIGASHI-OOSAKA JAPAN 579

Korea

KS Sports
Phone: 822 548 5408
FAX: 822 512 3230
SHIN SEUNG BLDG 4TH FLR, 115-4 NONHYUN-
DONG, KANGNAM-KU, SEOUL

INTERNATIONAL DISTRIBUTORS

Latvia

Veloserviss
Phone: 371 750 1292
Fax: 371 750 1298
1/1 HAPSALAS ST., RIGA, LV-1005

Luxembourg

Vertex Cycle Systems BV
Phone: 31 23 57 18184
FAX: 31 23 57 18606
FLEMINGSTRAAT 100A, 2041 VL ZANDVOORT
HOLLAND

Mexico

Tekno Bike
Phone: 52 8 336 5602
FAX : 52 8 338 5663
HUMBERTO LOBO #780, COL. DEL VALLE, GARZA
GARCIA, MEXICO, CP, 66220, Mexico

New Zealand

W.H. Whorrall & Co. Ltd.
Phone: 64 9 63 6 06 41
FAX: 64 9 63 6 06 31
43 FELIX ST
PENROSE, AUCKLAND
NEW ZEALAND

Norway

Hallman Sports
Phone: 46 18 56 16 00
FAX: 46 18 50 03 22
HALLNASGATAN 8, S-75228 UPPSALA, SWEDEN

Panama

Distribuidora Rali S.A.
Phone: 507 220-3844
FAX: 507 220-5303
VIA ESPANS EDIFICA CARCEP, P.O. BOX 87-
0852, PANAMA 7

Peru

Rojo Sports
Phone: 511 447 0838
FAX: 511 447 0838
AV. REPUBLICA DE, PANAMA 6513, LIMA 33

Poland

Giant Polska S.P. ZOO
Phone: 48 22 645 14 34
FAX: 48 22 645 14 36
AL NIEPODLEGLOSCI 221-4, 02-087 WARSZAWA

Portugal

Bicimax
Phone: 351 244 553276
FAX: 351 244 553187
APARTADO 34, 2431 MARINHA GRANDE

Russia

Sportex
Phone: 7095 288 4524
FAX: 7095 288 6888
KUDRINSKAYA PL., 1,, P.O.BOX 33, MOSCOW,
123242

St. Maarten

Tri-Sport International
Phone: 5995 43462
FAX: 5995 43928
8 AIRPORT BOULEVARD, SIMPSON BAY,
NAMIBIA

Singapore

Treknology Bikes 3
Phone: 65 466 2673
FAX: 65 466 7610
24 HOLLAND GROVE ROAD, SINGAPORE, 1545

Slovak Republic

Paul Lange Oslany
Phone: 42 1 862 5492 344
FAX: 42 1 862 5492 350
MIEROVA 854/37 OSLANY, 97247 SLOVAKIA

Slovenia

Proloco Trade
Phone: 386 64 380 200
FAX: 386 64 380 2022
ENOTA KRANJ, BRITOF 96A, 4000 KRANJ

South Africa

Coolheat (SA) (PTY) Ltd.
Phone: 27 11 807 5282
FAX: 27 11 807 2998
3 RUARGH STREET, PARK CENTRAL, P O BOX
740, JOHANNESBURG 2001

Spain

K. Motor Dealer S.L.
Phone: 34 9 1 637 70 97
FAX: 34 9 1 637 72 64
PARQUE INDUSTRIAL, EUROPOLIS EDIFICO
BRUSELA, BLOQUE 4, NAVE 1, LAS ROZAS
(MADRID), N/A, 28230

Sweden

Hallman Sports
Phone: 46 18 56 16 00
FAX: 46 18 50 03 22
HALLNASGATAN 8, S-75228 UPPSALA

Switzerland

Cilo Bike Service SA
Phone: 41 21 641 63 30
FAX: 41 21 641 63 82
CH. DE L'ORIO 30 A, CASE POSTALE 64, CH-
1032 ROMANEL S. LAUSANNE

Taiwan

Biketech Co. Ltd.
Phone: 886 22 694 5806
FAX: 886 22 694 6133
NO. 12 FU TEH ROAD, 266 LANE, 37 ALLEY
HSICHIH, TAIPEI HSIEN, TAIWAN, R.O.C.

Thailand

Probike Co. Ltd.
Phone: 662 254 1077
FAX: 662 254 1078
237/2 SARASIN ROAD, LUMPINNE, PATUMWAN,
BANGKOK, 10330

Turkey

EBSAT
Phone: 90 212 514 0525
FAX: 90 212 519 4846
EBSAT EMEK BISIKLET, EBUSUUD CAD NO.67,
34410 SIRKECI, ISTANBUL, 34410

United Kingdom

Madison
Phone: 44 181 385 3385
Fax: 44 208 345 3443
BUCKINGHAM HOUSE EAST, THE BROADWAY
STANMORE, MIDDLESEX HA7 4EA
UNITED KINGDOM

Uruguay

International Sports
Phone: 5982 782498
FAX: 5982 622532
AVDA. BRASIL 2567, 11800 MONTEVIDEO

Venezuela

Bike Sports
Phone 582 751 9709
FAX: 582 753 5071
CENTRO COMERCIAL IBARRA, PLANTA BAJA,
LOCAL 3-A CALLE GARCILAZO, COLINAS DE
BELLO, 0, CARACAS